


快速安接指南


Quick Installation Guide




www.comfast.com.cn
M0304153 Version 5.0

1 配件清单


Accessories List



金属扎带
Stainless Ties



旋转支架
Rotation Holder




POE电源适配器
POE Power Adapter



2 接口说明


Interface Description



- ① WAN口，用于POE供电及数据传输；
WAN Port: Used for POE power supply and data transmission.
- ② LAN口，用于POE供电及数据传输；
LAN Port: Used for POE power supply and data transmission.
- ③ Reset，用于复位设备，恢复出厂设置；
Reset: Used for rest to factory settings.
- ④ 指示灯，反应设备状态情况；
Indicator: Show the status of equipment.

3 典型连接示意图

Schematic Diagram of Typical Connection



- ① 设备LAN口可连接电脑进行模式设置，设置完成后再连接网络摄像机。

Connect LAN port of the device and the computer to set the device mode, then connect the network camera after mode settings is finished.

- ② 电源LAN口在设备模式设置完成后，连接互联网。



After mode settings finished, connect LAN port of the POE power adapter to the Internet.

4 扎带安装指南

Installation Guide for Tie

① 先将金属扎带A穿插在产品背面B位置的安装孔内，可根据抱杆的粗细对安装位置进行调节。

Make the tie A through B and adjust to suitable position according to pole thickness.




② 将主设备安装在抱杆上，用钳子将金属扎带A拉紧。

Install the main equipment on the pole and fasten stainless ties A with pliers.


③ 按住卡扣E,将主设备的盖板C取下，然后将网线D插入网口，最后将主设备的盖板C扣紧即可。

Press the buckle E, and remove the cover C of the main equipment, then plug the wire D into the ethernet port, finally fasten the cover C.



5 支架安装指南

Installation Guide for Bracket





① 先将金属扎带A穿插在产品背面B位置的安装孔内，可根据抱杆的粗细对安装位置进行调节。

Make the tie A through B and adjust to suitable position according to pole thickness.

② 先将支架安装在抱杆上，再将主设备安装在支架的抱杆上，用钳子将金属扎带A拉紧。

Install bracket on the pole, then install the main equipment on the bracket and fasten stainless ties A with pliers.




③ 按住卡扣E,将主设备的盖板C取下，然后将网线D插入网口，最后将主设备的盖板C扣紧即可。

Press the buckle E, and remove the cover C of the main equipment, then plug the wire D into the ethernet port, finally fasten the cover C .

6 钉墙安装指南



Installation Guide for Wall Mount



- ① F、G是钉子孔位。
F and G are nail holes.

- ② 将两个钉子钉在墙上，把设备的两个孔位对应钉子挂上即可。

Place two nails on the wall and hang up the CPE on the corresponding nails.



- ③ 按住卡扣E,将主设备的盖板C取下,然后将网线D插入网口,最后将主设备的盖板C扣紧即可。

Press the buckle E, and remove the cover C of the main equipment, then plug the wire D into the ethernet port, finally fasten the cover C .

版权信息

Copyright Information

声明

Statement

深圳市四海众联网络科技有限公司

版权所用，保留所有权利

**Shenzhen Four Seas Global Link Network
Technology CO.,Ltd.Company
all rights reserved.**

Without our official written permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means (electronic, mechanical, printing, recording or other possible means) or for the propagation of goods any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co., Ltd. Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee.

服务热线: 0755 83790059/83790659

制造商: 深圳市四海众联网络科技有限公司

地址: 深圳市龙华新区腾龙路淘金地大厦B座607-610室

网址: www.comfast.com.cn

Hotline: 0755 83790059/83790659

Manufacturer: Shenzhen Four Seas Global Link Network Technology Co., Ltd. Company

Address: Room 607-610, Block B Tao JINDI Electronic Business Incubation Base, Tenglong Road, Longhua District, Shenzhen, China

Website: www.szcomfast.com