

# 快速安接指南

## Quick Installation Guide




[www.comfast.com.cn](http://www.comfast.com.cn)

M0304245 Version 3.0

# 1 装箱清单 Packing list



主设备  
The Main Device




POE电源适配器  
POE Power Adapter




金属扎带  
Stainless Steel Ties

# 2 可选配件 Optional Accessories




POE电源适配器  
POE Power Adapter



多角度金属支架  
Multi Angle Metal bracket

### 3 接口说明 Interface Description





- ① LAN口，用于POE供电及数据传输；  
LAN Port: POE power supply and data transmission ;
- ② Reset，用于复位设备，恢复出厂设置；  
Reset: Restore to the factory settings;
- ③ WAN口，用于POE供电及数据传输。  
WAN Port: POE power supply and data transmission .

## 4 典型连接示意图

### Schematic Diagram Of Typical Connection

主设备



监控摄像头  
Security/IP camera

POE电源适配器  
POE Power Supply





PC

## 5 扎带安装指南

### Installation Guide for Tie

① 先将两条金属扎带A穿插在产品背面B位置的两处安装孔内，可根据抱杆的粗细对安装位置进行调节。

Insert two ties A into two holes B as picture shows. It can be adjusted by Pole thickness.




② 将主设备安装在抱杆上，用钳子将两条金属扎带A分别拉紧。

Install the main device on the pole and then fasten the ties A by pliers.


③ 按住卡扣E,将主设备的盖板C取下，然后将网线D插入网口，最后将主设备的盖板C扣紧即可。

Press the fastener E and take off the cover C. Then insert the cable D into the RJ45 port and cover it to finish the installation.



## 6 支架安装指南

### Installation Guide for Mount Bracket





① 先将两条金属扎带A穿插在产品背面B位置的两处安装孔内，可根据抱杆的粗细对安装位置进行调节。

Insert two ties A into two holes B as picture shows. It can be adjusted by Pole thickness.

② 先将金属支架A安装在抱杆上，再将主设备安装在金属支架的抱杆上，用钳子将两条金属扎带A分别拉紧。

First install the tie A to the mount bracket. Then install the main device on the pole of the mount bracket and then fasten the ties A by pliers.




③ 按住卡扣E,将主设备的盖板C取下，然后将网线D插入网口，最后将主设备的盖板C扣紧即可。

Press the fastener E and take off the cover C. Then insert the cable D into the RJ45 port and cover it to finish the installation.



## 7 钉墙安装指南

### Installation Guide for Nail Mount



- ① F、G是钉子孔位。  
F and G are the nail hole position

- ② 将两个钉子钉在墙上，把设备的两个孔位对应钉子挂上即可。  
Fix the main device by two nails properly.



- ③ 按住卡扣E,将主设备的盖板C取下,然后将网线D插入网口,最后将主设备的盖板C扣紧即可。  
Press the fastener E and take off the cover C. Then insert the cable D into the RJ45 port and cover it to finish the installation.

# 版权信息

## Copyright information

### 声明

Statement

**深圳市四海众联网络科技有限公司**

**版权所用，保留所有权利**

**Shenzhen Four Seas Global Link Network Technology**

**CO.,Ltd.Company**

**all rights reserved.**

Without our official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

**COMFAST** is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.-Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee

服务热线：0755 83790059/83790659

制造商：深圳市四海众联网络科技有限公司

地址：深圳市龙华新区腾龙路淘金地大厦B座607-610室

网址：www.comfast.com.cn

Manufacturer: Shenzhen Four Seas Global Link Network Technology Co., Ltd

Address: Room 607-610,Block B Tao JINDI Electronic Business

Incubation Base, Tenglong Road, Longhua District, Shenzhen,China

Hotline:0755 83790059/83790659

Website: www.szcomfast.com