Quick Installation Guide

In-wall AP

M0305289 V1.0

***Notes:** The product model in this guide is only for installation, not for actual product.

1 Installation Diagram

Notes: Solution 1: Single Device Settings: Get into the web setting page independently.
Solution 2: Multiple Devices Settings: Do centralized management settings and Local portal by AC core gateway.
(Notes: POE power and other devices which are not standard, pls refer to the packing list.)

2 Installation Way

2.1 Ceiling-mount Installation

① Pls refer to the position of the Ethernet port and find the plug-in hole at the buttom.

② Open the panel slightly with screwdriver.

2.2 Wall-mounted Installation

① Pls put the AP in the cassette and tighten the screw into the correspond hole.

② Press the panel of the AP into the cassette appropriately.

Notes: The guide is based on one kind of panel, and the installation of other panels is similar to this

3 Single Device Configuration

3.1 Connection Diagram

Notes: The WAN port is on the back of the device and the LAN port is on the front of the device.

3.2 Set the computer to obtain the IP address automatically, and connect the LAN port of the device to the device management interface.

3.3 The device is defaulted to be fat AP mode. The steps to enter the set interface as follows:

(1) Under default configuration, power on the device and wait 90 seconds untill the device to start.

(2) Connect the device' s LAN port with the computer by a network cable.

(3) Input 192.168.10.1 in the web browser to enter the set interface.

(4) Open the computer browser, and input 192.168.10.1 to get into the device login page. The device is defaulted as Router Mode. When you login at the first time, you need to set a password. The device language is compatible with Chinese and English to choose, and you can set up the language by the top right corner icon

3.4 When getting into the setting page, there are four working modes in the Wizard: AP Mode,Bridge Mode,Router Mode, Repeater Mode.

3.5 Click AP mode and set up IP Address and Subnet Mask. The IP address and Subnet mask should be within the same network segment as upper network and can’ t be conflict with IP address from upper network router. After settings, you can visit the device from the IP address you have set just now by connecting internet with WAN port of the device or POE adaper LAN port.

①Notes: In AP mode, the IP address from the other devices connected the AP will be allocated by the upper network router.

②The AP needs to set an intranet IP address (do not set the same IP address as the upper router). If want to manage the device, Manually set the IP address of the same network segment of the intranet IP.

3.6 AP Mode: You can set up 2.4G/5.8G wireless SSID, password, channel and country in advance. After setting up,the device’ s WAN port or POE adapter LAN port connected internet,other mobile devices can connect the SSID to surf the internet.

3.7 Bridge Mode: Pls ensure the WDS in upper network is enabled. AP device can set up intranet segment(do not set the same IP address as the upper router), and then select the wireless SSID signal you need to bridge(Distinguish between 5.8GHz and 2.4GHz) and input wireless password.
(Notes: The password is same as your upper network router)

Pls set the SSID and password for the device and click “Next” to finish settings.

3.8 Repeater Mode: The AP device can set the internal network segment (the gateway IP should not be the same as the upper device gateway IP). Next, select the name of the wireless SSID signal that you need to relay (distinguish between 5.8GHz and 2.4GHz) and input wireless password.
(Notes: The password is same as your upper network router).

Pls set the SSID and password for the device and click “Next” to finish settings.

3.9 Router Mode: There are three ways to surf the internet: PPPOE, Static, and DHCP. (Pls refer to router setting as reference)

Quick Installation Guide

Statement
Shenzhen Four Seas Global Link Network Technology CO.,Ltd.Company all rights reserved.

Without ours official writ permission, no unit or individual shall be copied, reproduced, transcribed or translated in part or whole book. In any form or by any means(electronic,mechanical,printing,recording or other possible means)or for the propagation of goods any commercial, profitable purposes.

COMFAST is the registered trademark of Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company. All other trademarks or registered trademarks mentioned in this document, by respective owners.

Product specifications and information mentioned in this manual are for reference on subject to updates without notice. Unless there are other special agreed, this manual is used only as a user guide. All statements, information, etc. are not constitute any form of guarantee.

Manufacturer: Shenzhen Four Seas Global Link Network Technology Co.,Ltd.Company
Address: Room 607-610,Block B Tao JINDI Electronic Business Incubation Base, Tenglong Road, Longhua District, Shenzhen, China
Hotline: 0755 83790059/83790659
Website: www.szcomfast.com